



*NOTE:
ALLOW ACCESS FOR WIRING
SCREW TERMINAL AND CABLE ENTRY
(SEE INSTALLATION INSTRUCTIONS)

DO NOT SCALE DRAWING	
TOLERANCES UNLESS OTHERWISE SPECIFIED	
DIMENSIONING ENGLISH [mm]	
FRACTIONAL ± 1/64	
ANGULAR: ± 2	
DECIMAL	IN. MM
.XXX ± .005	.010
.XX ± .015	.10
.X	.3

		NAME	DATE
DRAWN	Shane Russell	05/01/2012	MATERIAL
RELEASED			

ARMSTRONG INTERNATIONAL Copyright © 2010 ARMSTRONG INTERNATIONAL, INC.	
MODEL E40W	
REV	DWG
SHEET 1 OF 1	
MODEL E40W	